

SoloLift Battery Charger

Instruction Sheet



CE

 rifton®

User modifications

We recognize that some clients may benefit from modifications made in the field. However, we cannot be responsible for customer-modifications to our products without our supervision, testing, or evaluation.

Parts disclaimer

We are glad to supply the parts you requested. Although Rifton Equipment makes every effort to supply correct parts and instructions for repairing or refurbishing your equipment, you are responsible to make sure that the repairs or modifications are correctly and safely completed.



IMPORTANT

- Please save this Product Manual. Additional copies are available at www.rifton.com
- Please refer to the Rifton product catalog for our full warranty, or visit www.rifton.com

To order replacement parts

1. Locate the serial number of the product on the small white label.
2. Have this number available when you call **800.571.8198** for your customer service representative.

Use only replacement parts supplied by Rifton Equipment.

Installation

1. Remove the battery from the charger to access the mounting bracket.
2. Attach the charger to the wall near an outlet, using two screws as shown in the picture. Two screws are provided with the charger, however, they may not be suitable for every situation.
3. Plug the charger cord into wall outlet.

Charging

- Charge batteries 24 hours before first use and after any long period of inactivity.
- When the battery needs charging, an indicator light on the hand pendant will illuminate.
- Remove the battery from the control box, and secure to the wall-mounted charger.
- The batteries should be charged frequently to ensure maximum battery life.
- The charger and indicator light will shut off automatically when charging is complete.
- Charging normally takes approximately six hours.
- For best results, recharge fully after each day of SoloLift use.



Figure 1




Figure 2

Troubleshooting

Battery does not charge:

1. Make sure the battery contact plate is not damaged or broken.
2. Make sure the wall charger is plugged securely into the wall socket.
3. Contact Rifton.

 **WARNING:** Do not charge batteries in a wet area.

 Old batteries should be disposed of properly at an appropriate recycling facility.